

6a. PRINT / PRESS – HOVER MODELS ONLY

Your HOTRONIX HOVER PRESS® can be set up to utilize 4 different settings on hover or direct pressure. The options are listed below:

001 = Pressure (Time 1)	Pressure (Time 2)
002 = Hover (Time 1)	Pressure (Time 2)
003 = Hover (Time 1)	Hover (Time 2)
004 = Pressure (Time 1)	Hover (Time 2)

Once you have decided what setting is best for your application (1, 2, 3, or 4), follow the simple steps below:

- With Power switched to OFF position, hold down both Decrease (-) and Increase (+) mode buttons on the Control Panel. Switch power to ON position and continue to hold mode buttons down for 3 – 5 seconds.
- Press the mode (center) button once. 555 should appear on display.
- Press the mode (center) button again, at this time you may choose option 1, 2, 3, or 4 by pressing the increase (+) button. Once desired setting is selected, press the mode (center) button twice to return to the temperature Mode (Step 3)

6b. PRINT / PRESS – HOVER MODELS ONLY (cont.)

Once your equipment has reached the designated temperature:

- Position the garment and application and proceed to press and/or hover.
- Lower and lock the heat platen into the press or hover position. This procedure will start the automatic timing process.

The timer will automatically count down and lift the heat platen into the “UP” position when the 1st press or hover cycle is complete. Lower and lock heat platen for the 2nd press or hover cycle. The timer will automatically count down and lift heat platen when 2nd cycle is complete. ** Please be aware after time is complete – gas shocks will automatically release the platen into the “UP” position.

The time will automatically re-set and you are ready to continue with the next application.