



Press "SET UP"



Type in password: JAGUAR2 (JAGUAR on older models) and press "ENTER"

NOTE: do not use this password for anything besides this temperature calibration or warranty is void



Press "CALIBRATION"



Press "TEMPERATURE CALIBRATION"



Use +/- buttons to change temperature next to "TEMPERATURE CALIBRATION" to match reading on temperature strip



Press "SAVE" to save calibration, then "BACK" to return to the "CALIBRATION SETUP" screen



Press "PLATEN PRESSURE CALIBRATION"



Press "CALIBRATE" and wait for the Controller to dial into 2.5V and display the "SET MIN POINT" button at left



Open press and adjust the Pressure Adjustment Knob until the voltage reads 2.7V when locked down



While press is locked down at 2.7V, press "SET MIN POINT"



Open press and adjust the Pressure Adjustment Knob until the voltage reads either 3.1V or 3.2V when locked down



While press is locked down at 3.1V or 3.2V,
press "SET MAX POINT"



Press "SAVE" to save calibration, then
"BACK" repeatedly to return to main
operation screen